

JET

JPL-358

PEN LATHE

**708329M
230/50/1**

**PARTS LIST
ERSATZTEILLISTE
LISTE DE PIECES**

WMH Tool Group AG

Bahnstrasse 24, CH – 8603 Schwerzenbach

www.wmhtoolgroup.ch; info@wmhtoolgroup.ch


Tel +41 (0) 1 806 47 48

Fax +41 (0) 1 806 47 58

P-708329M 01/04



Parts Breakdown for JPL-358 Pen Lathe



Parts List for JPL-358 Pen Lathe

Index	Part		Description	Size	Quantity
No.	No.				
	JPL358-HA		Headstock Assembly (Items 1 thru 8)		1
1	JPL358-101		Headstock		1
2	BB-6003ZZ		Ball Bearing	6003ZZ	1
3	JPL358-103		C-Ring	S-17	1
4	JPL358-104		Spindle Pulley		1
5	JPL358-105		End Cover		1
6	JPL358-106		Main Spindle		1
7	BB-6003VV		Ball Bearing	6003VV	1
8	TS-1521031		Socket Set Screw	M4x0.7Px8	3
9	JPL358-109		Spur Center		1
10	JPL358-110		Flat Washer	M6x16D	3
11	JPL358-111		Connect Plate		4
12	TS-1482061		Hex Cap Screw	M6x1.0Px30	2
13	TS-1540041		Hex Nut	M6x1.0Px30	2
14	TS-1502021		Socket Head Cap Screw	M5x0.8Px10	1
15	TS-1550061		Flat Washer	M8	1
16	BB-608ZZ		Ball Bearing	608ZZ	2
17	JPL358-117		C-Ring	S-8	1
18	JPL358-118		Joint Plate		1
19	JPL358-119		Pulley Cover		1
20	JPL358-120		Knob		1
21	TS-2284202		Phillips Pan Head Machine Screw	M4x0.7Px20	1
22	TS-1550021		Flat Washer	M4	1
23	TS-1541001		Nylon Nut	M4x0.7P	1
24	TS-2285162		Phillips Pan Head Machine Screw	M5x0.8Px16	5
25	JPL358-125		Motor Pulley		1
26	JPL358-126		Poly-V Belt	112H	1
27	TS-2361041		Lock Washer	M4	2
28	JPL358-128E		Motor		1
29	JPL358-129E		Bed		1
30	JWL1442-118E		Switch		1
31	JPL358-131		Handle Lock		2
32	JPL358-132		Tool Rest Base		1
33	JPL358-133		Flat Washer	M6x19D	1
34	JPL358-134		Special Wrench		2
35	JPL358-135		Bolt	M6x1.0Px25	1
36	JPL358-136		Tool Rest		1
37	JPL358-137		Tailstock		1
38	JPL358-138		Cover		1
39	JPL358-139		Cover		1
40	JPL358-140		Quill		1
41	JPL358-141		Threaded Stud	M6x1.0Px14	1
42	JPL358-142		Lead Screw		1
43	JPL358-143		Bush		1
44	JPL358-144		Copper Washer		1
45	JPL358-145		Handwheel		1
46	TS-2331051		Cap Nut	M5x0.8P	1

Parts List for JPL-358 Pen Lathe (continued)

Index	Part			
No.	No.	Description	Size	Qty.
	JPL358-LCK	Live Center Kit (Items 47 thru 49)		1
47	JPL358-147	Live Center Body		1
48	BB-626VV	Ball Bearing	626VV	1
49	JPL358-149	Tip		1
50	JPL358-150E	Power Cord		1
52	JPL358-152	Copper Plate		1
53	TS-1532042	Phillips Pan Head Machine Screw	M4x0.7Px12	2
54	JPL358-154	Star Washer	M4	4
55	TS-1540021	Hex Nut	M4x0.7P	4
56	TS-1532032	Pan Head Screw	M4x0.7Px10	2
57	JPL358-157	Clamp		1
58	JPL358-158	Cover		1
59	TS-1533032	Phillips Pan Head Machine Screw	M5x0.8Px10	4
60	JML-79	Goggles		1
	JPL358-PMA	Pen Mandrel Assembly (Items 61 thru 64)		1
61	JPL358-161	Spacer		9
62	JPL358-162	Taper		1
63	JPL358-163	Shaft		1
64	JPL358-164	Lock Nut		1
65	JPL358-165	Knockout Rod		1
66	JPL358-166	Skew Chisel		1
67	JPL358-167	Parting Chisel		1
68	JPL358-168	Domed Scraper Chisel		1
69	JPL358-169	Bolt	M6x1.0Px30	1
70	JPL358-170	L Plate		1
71	JPL358-171	JET Logo		1
72	JPL358-172E	I.D Label		1
74	JPL358-174E	Speed Label		1
75	JPL358-175E	Motor Label		1
76	JPL358-176E	EMC		1

JPL-358
708329M

230/50/1

	colour of strands	Litzenfarben	couleur des cordons
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
YE	yellow	gelb	jaune
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
OG	orange	orange	orange
VT	violet	violett	violet

	meaning of symbol	Bedeutung der Zeichen	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
E	electronic unit	Elektronik Einheit	unité électronique
F	fuse	Sicherung	fusible
RS	reversing switch	Drehrichtungsschalter	commu. droite/gauche
S	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschutzschalter	déclencheur surcharge
LS	limit switch	Positionendschalter	micro

