

# JET

**JSG-96**

**COMBI DISC/BELT SANDER**

**708595M  
230/50/1**

**PARTS LIST  
ERSATZTEILLISTE  
LISTE DE PIECES**


**WMH Tool Group AG**  
Bahnstrasse 24, CH-8603 Schwerzenbach  
[www.wmhtoolgroup.ch](http://www.wmhtoolgroup.ch); [info@wmhtoolgroup.ch](mailto:info@wmhtoolgroup.ch)

Tel +41 (0) 1 806 47 48  
Fax +41 (0) 1 806 47 58

P-708595M 03/02



**Disc Sander Assembly**



## Parts List For The JSG-96 Disc/Grinder Sander


### Disc Sander Assembly

<b>Index</b>	<b>Part</b>		<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.				
1	JSG96-101		Base .....		1
2	JSG96-102E		Motor .....		1
	JSG96-102AE		Starting Capacitor (not shown).....		1
	JSG96-102BE		Running Capacitor (not shown).....		1
3	TS-1550041		Flat Washer .....	M6 .....	4
4	TS-1551041		Lock Washer .....	M6 .....	7
5	TS-1540041		Hex Nut .....	M6 .....	1
6	JSG96-106		Disc Cover .....		1
7	JSG96-107		Screw w/Washer .....	1/4x3/8 .....	3
8	JSG96-108		Air Controller .....		1
9	TS-081B05		Screw .....	1/4x1/2 .....	2
10	JSG96-110		Lock Knob .....		1
11	JSG96-111		Tap Screw .....	1/4x1 .....	1
12	JSG96-112		Key .....	5x5x25 .....	1
13	JSG96-113		Disc .....		1
14	JSG96-114		Set Screw .....	#10x3/8 .....	1
15	JSG96-115		Sanding Disc .....		1
16	JSG96-116		End Cover .....		1
17	JSG96-117		Pin .....		1
18	JSG96-118		Compound Table.....		1
19	JSG96-119		Table Bracket .....		1
20	JSG96-120		Trunnion .....		2
21	JSG96-121		Pin .....		2
22	JSG96-122		Hex Socket Cap Screw .....	#10x5/8 .....	2
23	JSG96-123		Table Support w/Scale .....		1
24	TS-0680031		Flat Washer .....	5/16 .....	2
25	TS-0051021		Hex Head Screw .....	5/16x5/8 .....	2
26	JSG96-126		Lock Handle .....		1
27	JSG96-127		Screw .....	1/4x3/8 .....	7
28	JSG96-128		Pointer .....		1
29	TS-0270031		Set Screw .....	5/16x3/8 .....	2
30	JSG96-130		Rod.....		1
31	JSG96-131		Set Screw .....	1/4x1 .....	1
32	TS-0561011		Hex Nut .....	1/4 .....	1
33	JSG96-133		Lock Handle .....		1
34	JSG96-134E		Switch Plate .....		1
35	JSG96-135E		Switch .....		1
36	JSG96-136		Plate .....		1

37 .....	JSG96-137 .....	Screw w/Flange.....	#10x3/8.....	17
38 .....	TS-0680011 .....	Flat Washer .....	3/16 .....	1
39 .....	JSG96-139E .....	Strain Relief .....	.....	1
40 .....	JSG96-140E .....	Power Cord .....	.....	1
41 .....	JSG96-141 .....	Dust Chute .....	.....	1
42 .....	JSG96-142 .....	Circle Gauge .....	.....	1
43 .....	JSG96-143 .....	Tip .....	.....	1
44 .....	JSG96-144 .....	Set Screw .....	1/4x1/4 .....	2
45 .....	JSG96-145 .....	Set Screw .....	M4x6 .....	1
46 .....	JWBS18-403 .....	Miter Gauge Body .....	.....	1
47 .....	JSG96-147 .....	Guide Bar .....	.....	1
48 .....	JWBS18-401 .....	Lock Handle .....	.....	1
49 .....	JWBS20-156 .....	Guide Disc .....	.....	1
50 .....	JSG96-150 .....	Pan Head Screw .....	1/4x5/16 .....	1
51 .....	JSG96-151 .....	Screw .....	#10x5/16 .....	1
52 .....	JWBS18-406 .....	Pointer .....	.....	1
53 .....	JSG96-153 .....	Cord Protector .....	.....	1
54 .....	JSG96-154E .....	I.D. Label .....	.....	1
55 .....	JSG96-155 .....	Indication Label .....	.....	1
.....	JSG96-MGA .....	Miter Gauge Assembly .....	.....	1
.....	JSG96-CGA .....	Circel Gauge Assembly .....	.....	1
56 .....	JSG96-156 .....	Roll Pin .....	3x12 .....	1
57 .....	JSG96-157E .....	Motor Label .....	.....	1



Belt Sander Assembly Breakdown




# Belt Sander Assembly

Index No.	Part No.	Description	Size	Qty.
1	JSG96-201	Bracket		1
2	TS-0208071	.Hex Socket Cap Screw	5/16x1-1/4	1
3	JSG96-203	.Pin		1
4	JSG96-204	.Fixed Plate		1
5	TS-0680021	.Flat Washer	1/4	8
6	JSG96-127	.Screw	1/4x3/8	4
7	JSG96-207	.Key	5x5x70	1
8	JSG96-208	.Drive Drum		1
9	JSG96-209	.Lock Nut	5/8-18UNF	1
10	JSG96-210	.Belt Support		1
11	JSG96-211	.Hex Socket Cap Screw	5/16x5/8	4
12	TS-0720081	.Lock Washer	5/16	5
13	TS-0680031	.Flat Washer	5/16	6
14	TS-0270031	.Set Screw	5/16x3/8	4
15	JSG96-215	.Bracket		1
16	TS-0208061	.Hex Socket Cap Screw	5/16x1	1
17	TS-0561021	.Hex Nut	5/16	1
18	JSG96-218	.Rod		1
19	JSG96-219	.Pad		1
20	JSG96-220	.Set Screw	1/4x3/8	1
21	JSG96-221	.Follow Roller		1
22	BB-6201ZZ	.Ball Bearing		2
23	JSG96-223	.C-Ring	STW-11	2
24	JSG96-224	.Shaft		1
25	JSG96-225	.Bushing		1
26	TS-0680041	.Flat Washer	3/8	1
27	JSG96-227	.Lock Nut	3/8	1
28	JSG96-228	.Roll Pin	4x20	1
29	JSG96-229	.Support Bracket		1
30	JSG96-230	.Micro-Adjusting Seat		1
31	TS-0207011	.Hex Socket Cap Screw	1/4x1/2	6
32	JSG96-232	.Screw		1
33	JSG96-233	.Adjusting Knob		1
34	JSG96-234	.Spring		1
35	JSG96-235	.Lock Nut	M6	1
36	JSG96-236	.Washer		2
37	JSG96-237	.Disc Spring		2
38	JSG96-238	.Lock Handle		1
39	JSG96-239	.Roll Pin	3x20	1
40	JSG96-240	.Spring		1
41	JSG96-241	.Eccentric Handle		1
42	JSG96-242	.Hex Socket Cap Screw	1/4x1-1/4	1
43	JSG96-243	.Lock Nut	1/4	2
44	JSG96-244	.Air Controller (Belt)		1
45	JSG96-245	.Dust Chute		1
46	JSG96-246E	.Hex bolt	1/4x1/2	1
47	JSG96-247	.Flat Washer	1/4x3/4	4
48	JSG96-248	.Back Cover		1
49	JSG96-249	.Sanding Belt		1
50	JSG96-250	.Belt Table		1
51	JSG96-251	.Trunnion		2
52	TS-0050021	.Hex Socket Cap Screw	1/4x5/8	2
53	JSG96-253	.Guide Pin		2
54	TS-0561011	.Hex Nut	1/4	2

55 .....	JSG96-255.....	Set Screw .....	1/4x3/4.....	2
56 .....	JSG96-256.....	Lock Handle .....	.....	2
57 .....	JSG96-257.....	Graphic Pad .....	.....	1
58 .....	JSG96-155.....	Indication Label .....	.....	1
59 .....	JSG96-259.....	Loosen/ Tighten Label.....	.....	1
60 .....	JSG96-260.....	Flat Washer .....	1/4x9/16x1/8.....	2
61 .....	JSG96-261.....	Serrated Plate .....	.....	2
62 .....	JSG96-262.....	Philips Tap Screw .....	M3x10.....	4
63 .....	TS-0720071 .....	Lock Washer .....	1/4.....	2
64 .....	JSG96-264.....	Set Screw .....	1/4x1-1/2 .....	1
65 .....	JSG96-265.....	Left Cover .....	.....	1
66 .....	JSG96-266.....	Right Cover .....	.....	1

## Close Stand Breakdown



## Closed Stand Assembly

### **Index Part**


No.	No.	Description	Size	Qty.
1	JSG96-301	Base .....		1
2	JSG96-302	Lock Nut .....	3/8.....	4
3	PJE-S05	Wheel .....		4
4	JSG96-304	Hex Head Screw .....	3/8x2-1/2 .....	8
5	JSG96-305	Shaft .....		1
6	PJN-S04	Eccentric Cam .....		2
7	JSG96-307	Set Screw .....	M6x10 .....	2
8	JSG96-308	Spring .....		2
9	JSG96-309	Roll Pin .....	4x16 .....	2
10	PJN-S02	Foot Brake .....		1
11	JSG96-311	Lock Nut .....	M10x1.5 .....	1
12	TS-0720091	Lock Washer .....	3/8.....	4
13	TS-0680041	Flat Washer .....	3/8.....	4
14	JSG96-314	Tool Shelf .....		1
15	TS-0060031	Hex Head Screw .....	3/8x3/4 .....	1
16	JSG96-316	Washer .....	3/8x1-1/8 .....	1
17	JSG96-317	JET Plaque .....		1
18	JSG96-318	Door .....		1
19	JSG96-319	Latch .....		1
20	JSG96-320	Screw .....	M3x4 .....	2
21	JSG96-321	Door Pivot .....		1
22	JSG96-127	Screw .....	1/4x3/8 .....	2
23	TS-0561011	Hex Nut .....	1/4 .....	2
24	JSG96-324	Braking Label .....		1

JSG-96


708595 M

	colour of strands	Litzenfarben	couleur des cordons
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
YE	yellow	gelb	jaune
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
OG	orange	orange	orange
VT	violet	violett	violet

	meaning of symbol	Bedeutung der Zeichen	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
E	electronic unit	Elektronik Einheit	unité électronique
F	fuse	Sicherung	fusible
RS	reversing switch	Drehrichtungsschalter	commu. droite/gauche
CS	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschutzschalter	déclencheur surcharge
LS	limit switch	Positionendschalter	micro



S



M