

# J E T

**JWBS-14**

**WOODWORKING BANDSAW**

**10000100M**

**230/50/1**

**PARTS LIST  
ERSATZTEILLISTE  
LISTE DE PIÈCES**

**WMH Tool Group AG**

Bahnstrasse 24, CH-8603 Schwerzenbach

[www.wmhtoolgroup.ch](http://www.wmhtoolgroup.ch); [info@wmhtoolgroup.ch](mailto:info@wmhtoolgroup.ch)




Tel +41 (0) 1 806 47 48

Fax +41 (0) 1 806 47 58

P-10000100M 03/02



Breakdown for JWBS-14



## Parts List for JWBS-14


<b>Index</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
1	130001W	Body .....		1
2	130004W	Upper Door Ass'y .....		1
3	130005W	Lower Door Ass'y .....		1
4	SR060200	Socket Cap Bolt.....	M6x10 .....	4
5	WS060000	Spring Washer.....	M6.....	4
6	SR059300	Socket Cap Bolt.....	M5x12 .....	1
7	130017	Bias Shaft .....		1
8	130018	Bias Shaft Clamp Seat .....		1
9	130020	Adjust Shoes .....		1
10	SM080400	Socket Cap Bolt.....	M8x20 .....	1
11	NH081300	Nut .....	M8.....	1
12	130041	Handle .....		1
13	SF059200	Pan Head Bolt .....	M5x8.....	4
14	SF040700	Pan Head Bolt .....	M4x35 .....	2
15	136012	Limit Switch .....	AZD-1112 .....	1
16	130046	Cover .....		1
17	130047	Fixed Plate .....		1
18	136009	Switch Bushing.....		1
19	SS050100	Set Screw .....	M5x5 .....	1
20	130003	Copper Coin .....		1
21	SR060200	Socket Cap Bolt.....	M6x10 .....	2
22	WS080000	Spring Washer.....	M8.....	4
23	SJ080400	Socket Cap Bolt.....	M8x20 .....	4
24	412040	Lock Knob .....	M8x25 .....	1
25	130011	Upper Support Bracket Post .....		1
26	SN040100	Socket Cap Bolt.....	M4x5 .....	6
27	130032	Spring Piece .....		1
28	130012	Adjust Gear .....		1
29	135043	Bushing .....		1
30	130016	Gear Fixed.....		1
31	WS060000	Spring Washer.....	M6.....	2
32	SR060200	Socket Cap Bolt.....	M6x10 .....	2
34	SR060700	Socket Cap Bolt.....	M6x35 .....	1
35	SN040100	Socket Cap Bolt.....	M4x5 .....	3
36	130010	Gear Row .....		1
37	620029	Adjust Nut .....		2
38	130009	Guide Shaft .....		1
39	130025	Change Shaft .....		1
40	135073	Step Screw .....		1
41	135054	Plastic Washer .....	M6.....	1
42	NH061000	Nut .....	M6.....	1
43	150015	Spacing Sleeve .....		2
44	BB620002	Ball Bearing.....	6200ZZ .....	2
45	SF069200	Pan Head Bolt .....	M6x8 .....	2
46	150013	Thumb Screw .....	M6x16 .....	3
47	150006	Support Bracket.....		2
48	150011	Block Guide .....		4
49	150005	Upper Support Bracket Post .....		1
50	130030	Free Board .....		1
51	130031	Blade Cover .....		1
52	SH060200	Hex Head Bolt .....	M6x10 .....	2
53	WF061301	Flat Washer .....	M6.....	2
54	SF060200	Pan Head Bolt .....	M6x10 .....	2
55	130033	Cam .....		1
56	130044	Fixed Ring .....		1
57	SS050100	Set Screw .....	M5x5 .....	1
58	130036	Adjust Screw .....		1
59	130022	Support Seat .....		1

60	130048	Spring	1
61	130023	Indicator	1
62	130019	Free Nut	1
63	990654	Lock Knob	M8x45
64	990657	Knob Nut	1
65	WF061310	Flat Washer	M6
66	991608	Pull Nut	M8
67	130015	Upper Wheel Fixed Seat	1
68	130028	Free Key	12x12
69	SR089400	Socket Cap Bolt	M8x16
70	WS080000	Spring Washer	M8
71	WF082320	Flat Washer	M8
72	130026	Revolving Spindle	1
73	130006	Upper Wheel Jump Seat	1
74	PS053500	Spring Pin	5x35
75	130007	Upper Wheel Shaft	1
76	WW152203	Waves Washer	2
77	170006	Upper Wheel	1
78	150035	Wheel Tire	2
79	SH089400	Hex Head Bolt	M8x16
80	WS080000	Spring Washer	M8
81	WF081818	Flat Washer	M8
82	BB620201	Ball Bearing	6202ZZ
83	RR350000	Retaining Ring	R35
84	130035	Lower Wheel	1
85	LJ019550	Belt	195J5
86	NH182601	Nut	M18
87	WS180000	Spring Washer	M18
88	130002	Lower Wheel Shaft	1
89	130042	Left Cover	1
90	NH081300	Nut	M8
91	SS080400	Set Screw	M8x20
92	135013	Cover	1
93	SF059200	Pan Head Bolt	M5x8
94	412007W	Inlet	1
95	SF060200	Pan Head Bolt	M6x10
96	MH130001	Motor	1
97	KP050520	Key	5x5x20
98	SS060200	Set Screw	M6x10
99	130027	Motor Pulley	1
100	SR080400	Socket Cap Bolt	M8x20
101	135041	Knob	2
102	NL061000	Nylon Nut	M6
103	150031	Pin	2
104	SF059100	Pan Head Bolt	M5x6
105	130043	Right Cover	1
106	150010	Adjusting Nut	4
107	SS080801	Adjusting Screw	M8x40
108	150014	Thumb Screw	M6x12
109	170752	Lower Support Bracket Post	1
110	130014	Thumb Screw	M6x24
111	130054	Point	1
112	SG069300	Hex Head Flange Bolt	M6x12
113	WF083030	Flat Washer	M8
114	WS080000	Spring Washer	M8
115	SR080500	Socket Cap Bolt	M8x25
116	170507	Brush	1
117	SF059200	Pan Head Bolt	M5x8
118	SH080600	Hex Head Bolt	M8x30
119	WS080000	Spring Washer	M8
120	130021	Trunnion Support Bracket	1
121	SH081600	Hex Head Bolt	M8x80

122	NH081300	Nut	M8	1
123	110049	Pointer		1
124	SP059100	Pan Head Bolt	M5x6	1
125	150045	Lock Knob	M10	2
126	135010	Table Insert		1
127	130045	Table Pin		1
128	130034	Table		1
129	SH101003	Hex Head Bolt	M10x50	2
130	100041	Trunnion Clamp Shoes		2
131	100042	Trununion		2
132	100051	Scale		1
133	SG069300	Hex Head Flange Bolt	M6x12	6
134	130024	Saw Blade	L2557Xw9.5	1
135	SF059200	Pan Head Bolt	M5x8	4
136	SP040200	Pan Head Bolt	M4x10	2
137	SP059300	Pan Head Bolt	M5x12	2
138	WE050000	Star Washer	M5	2
139	NH050500	Nut	M5	2
140	IC130005	Power Cord		1
141	IM130001	Motor Cord		1
142	SF059200	Pan Head Bolt	M5x8	2
143	709409	Strain Relief		1
144	135056	Plate		1
145	130050W	Switch Plate		1
146	994651	Switch		1
147	IC130006	Limit Switch Cord		1
148	AB198101	Miter Guide		1
	198101	Guide Bar		1
	198102	Guide		1
	198103	Nylon Washer		1
	198104	Handle		1
	198105	Miter Gauge Body		1
	198106	Guide		1
	198107	Shaft		1
	SN069200	Socket Cap Bolt	M6x6	1
	SF059200	Pan Head Bolt	M5x8	1
150	130055	Fixed Board		1
151	130039W	Extend Table		1
152	SH069400	Hex Head Bolt	M6x16	4
153	NF061000	Nut	M6	4
154	WF061300	Flat Washer	M6	4
155	JRF-14R	Rip Fence		1
157	130049	Fixed Plate		1
158	SH080400	Hex Head Bolt	M8x20	3
159	WS080000	Spring Washer	M8	3
160	WF081818	Flat Washer	M8	3
161	709410	Bell Strain Relief		1



**Breakdown for Stand**




### Parts List for Stand

Index	Part No.	Description	Size	Qty.
1	100144W	Stand		2
2	100164W	Side Cover		2
3	SC089400	Carriage Bolt	M8x16	8
4	NF061300	Nut	M8	8
5	SH069400	Hex Head Bolt	M6x16	8
6	WF061310	Flat Washer	M6	8
7	NF061000	Nut	M6	8

## JRF-14R Parts List

Index No.	Part No.	Description	Size	Quantity
1.....	JWBS14-F01 .....	JET Plaque .....		1
2.....	JWBS18-431 .....	Knob .....		1
3.....	JWBS18-432 .....	Lock Handle .....		1
4.....	JWBS18-433 .....	Lock Plate .....		1
5.....	JWBS18-434 .....	Pad .....		5
6.....	JWBS18-435 .....	Pin .....		1
7.....	JWBS18-436 .....	Pin .....		1
8.....	JWBS18-430 .....	Fence Body .....		1
9.....	JWBS18-422 .....	Pointer .....		1
10.....	JWBS18-441 .....	Star Washer .....		1
11.....	JWBS18-440 .....	Screw .....	3/16 x 14 .....	1
12.....	JWBS14-F12 .....	Fence .....		1
13.....	JWBS18-439 .....	Flat Washer* .....	5/16 .....	4
14.....	TS-0720081.....	Lock Washer* .....	5/16 .....	4
15.....	TS-0081031.....	Hex Cap Bolt* .....	5/16 x 3/4 .....	4
16.....	JWBS14-F16 .....	Knob* .....		1
17.....	JWBS18-444 .....	Sliding Pad* .....		1
18.....	TS-0561011.....	Hex Nut* .....	1/4" .....	2
19.....	TS-0680021.....	Falt Washer* .....	1/4" .....	8
20.....	TS-0720071.....	Lock Washer* .....	1/4" .....	8
21.....	JWBS18-445 .....	Rear Hook* .....		1
22.....	JWBS14-F22 .....	Resaw Kit* .....		1
23.....	JWBS14-F23 .....	Scale .....		1
24.....	JWBS14-F24 .....	Guide Rail .....		1
25.....	JWBS14-F25 .....	Front Rail .....		1
26.....	TS-1482041.....	Hex Cap Bolt* .....	M6 x 20 .....	7
27.....	JWBS14-F27 .....	Rear Rail .....		1



JWBS-14  
10000100 M

230/50/1

	colour of strands	Litzenfarben	couleur des cordons
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
YE	yellow	gelb	jaune
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
OG	orange	orange	orange
VT	violet	violett	violet

	meaning of symbol	Bedeutung der Zeichen	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
E	electronic unit	Elektronik Einheit	unité électronique
F	fuse	Sicherung	fusible
RS	reversing switch	Drehrichtungsschalter	commu. droite/gauche
CS	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschutzschalter	déclencheur surcharge
LS	limit switch	Positionsendschalter	micro

